

Interior Sconces



W166-CS1



W167-C10



W168-CS1

W166-CS1 candleburning, 3" h × 2" w backplate with straight shade, 5" standout

W167-C10 candleburning, single arm, 4" h × 2" w backplate, 8" standout

W167-C20 candleburning, adjustable double arm, 4" h × 2" w backplate

W167-C30 candleburning, adjustable triple arm, 4" h × 2" w backplate

W168-CS1 candleburning, 4" h × 3 1/4" w backplate, 7 1/2" standout

W169-C10 candleburning, single arm, 3" h × 2" w backplate, 5" standout

W169-C20 candleburning, double arm, 3" h × 2" w backplate, 4 1/2" standout, 7 1/2" wide

W170-E10 electrified, single arm, 5 1/4" square backplate, 11" standout

W170-E20 electrified, double arm, 5 1/4" square backplate, 7 1/4" standout, 17" wide

W170-ES1 electrified, single arm with shade, 5 1/4" square backplate, 10 1/4" standout

W170-ES2 electrified, double arm with shades, 5 1/4" square backplate, 8 1/4" standout, 17" wide



W169-C10



W170-CS1